



NOTE:
 BARD 8403-066 CONTROLLER
 MUST BE USED WITH THESE
 UNITS. A THERMOSTAT WILL NOT WORK.

Control Panel

Condenser Section

Wires Connect if Option Not Used

	Factory	Field	Optional
High Voltage			
Low Voltage			

99 Wire Identification numbers for Bard use only.

WARNING
 USE COPPER CONDUCTORS
 ONLY SUITABLE FOR AT LEAST
 75° C.

DANGER
 ELECTRICAL SHOCK HAZARD
 DISCONNECT POWER BEFORE
 SERVICING.

4095-275 D