



50 HZ ONLY  
IF APPLICABLE

Standard  
Diagram

Line 1 to power source or optional heater package  
Line 2 to power source or optional heater package  
Line 3 to power source or optional heater package

**A**  
Wires Connect  
if Option Not  
Used

**99**  
Wire Identification numbers  
for Bard use only.

**B**  
Jumper is factory installed  
as a component of a 0KW  
heater package option.

**WARNING**  
USE COPPER CONDUCTORS  
ONLY SUITABLE FOR AT LEAST  
75° C.

**DANGER**  
ELECTRICAL SHOCK HAZARD  
\*DISCONNECT POWER BEFORE  
SERVICING.

	Factory	Field	Optional
High Voltage			
Low Voltage			