



USE COPPER CONDUCTORS ONLY
SUITABLE FOR AT LEAST 75° C

COMPONENT CODE			
CC	COMPRESSOR CONTACTOR	LAB	LOW AMBIENT BYPASS
CCH	COMPRESSOR CRANKCASE HEATER	LAC	LOW AMBIENT CONTROL
COMP	COMPRESSOR	LBP	LOW PRESSURE BYPASS
DCC	DUAL FAN CAPACITOR	LPC	LOW PRESSURE CONTROL
DFC	DEFROST CONTROL	LS	LIMIT SWITCH
EHR	EMERGENCY HEAT RELAY	OFM	OUTDOOR FAN MOTOR
GND	GROUND	OFM	OUTDOOR FAN RELAY
H1	HEAT STRIP #1	PL1	PLUG #1
H2	HEAT STRIP #2	PD	PULL DISCONNECT
HC1	HEATER CONTACTOR #1	RV	REV. VALVE SOLINOID
HC2	HEATER CONTACTOR #2	SK	START KIT
HPC	HIGH PRESSURE CONTROL	T	TRANSFORMER
IBC	INDOOR BLOWER CAPACITOR	TB	TERMINAL BLOCK
IBM	INDOOR BLOWER MOTOR	TBL	LOW VOLTAGE TERMINAL BLOCK
IBR	INDOOR BLOWER RELAY	TCO	THERMAL CUTOFF

▲, ▲ Labeled wires connect if no options used.

▲ FOR LOW SPEED CONNECT BLACK AND ORANGE WIRES TOGETHER AND INSULATE. CONNECT RED WIRE TO TERMINAL 1 OF IBC.

▲ REMOVE JUMPER FOR OUTDOOR THERMOSTAT

	FACTORY STD.	FIELD	OPTIONAL
HIGH VOLTAGE	————	----	-----
LOW VOLTAGE	————	----	-----
ACCESSORY	————	----	-----

COLOR CODE			
BK	BLACK	Y	YELLOW
BR	BROWN	G	GREEN
R	RED	BL	BLUE
O	ORANGE	W	WHITE
		Y	VIOLET
		(PR)	PURPLE
		BY	GRAY
		(S)	SLATE
		T	TAN
		PK	PINK
		L	LAVENDER

BARD MFG. CO.
4096-310 F