



For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

460-60-3
Per Nameplate L1 L2 L3
Hi Voltage Field Connection
Hi Voltage Field Connection
Hi Voltage Field Connection
Red

Evaporator Section

Condenser Section

WARNING
USE COPPER CONDUCTORS
ONLY SUITABLE FOR AT LEAST
75° C.

DANGER
*ELECTRICAL SHOCK HAZARD
*DISCONNECT POWER BEFORE
SERVICING.

	Factory	Field	Optional
High Voltage			
Low Voltage			

Wire Identification numbers for Bard use only.
4096-385

NOTE: JUMPER PLUG MUST BE INSTALLED WHEN NO VENT OPTION IS INSTALLED

A → **A**
Remove wire for (-)10%
Airflow Full & Part Loads

Same Letter Designated Wires Connect if Option Not Used
"A" No Control Option
"B" & "C" Only LAC Option