



Standard Diagram Heater Package Assembly

WARNING
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
ELECTRICAL SHOCK HAZARD DISCONNECT POWER BEFORE SERVICING.



Wires Connect if Option Not Used	Wire Identification numbers for Bard use only		
	Factory	Field	Optional
High Voltage			
Low Voltage			

Jumper Installed if no heater package used.

WARNING
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
ELECTRICAL SHOCK HAZARD DISCONNECT POWER BEFORE SERVICING.