



For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

230/208-60-3 Per Nameplate
Hi Voltage Field Connections

R Vent option only

WARNING
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
ELECTRICAL SHOCK HAZARD
DISCONNECT POWER BEFORE SERVICING.

A → **A**
Same Letter Designated Wires Connect if Option Not Used
"A" & "C" No Control Option
"B" Only Freeze Stat

NOTE: JUMPER PLUG MUST BE INSTALLED WHEN NO VENT OPTION IS INSTALLED

	Factory	Field	Optional	Wire Identification numbers for Bard use only.
High Voltage				
Low Voltage				
				4100-227 C