



▲▲▲▲ Labeled wires connect if no options used.

▲ Install jumper for hi speed blower oper. on models 36, 42, 48, and 60.

▲ Remove jumper when Low Amb. Bypass is installed.

	Factory	Field	Optional
High Voltage			
Low Voltage			

**WARNING**  
USE COPPER CONDUCTORS  
ONLY SUITABLE FOR AT LEAST  
75° C.

**DANGER**  
ELECTRICAL SHOCK HAZARD  
DISCONNECT POWER BEFORE  
SERVICING.

**Bard**  
SINCE 1914

**Bard Mfg. Co.**  
Bryan, Ohio

**4100-319**