









For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

R Vent option only

230/208-60-3
Per Nameplate
Hi Voltage
Field Connections



Condenser Section

	Factory	Field	Optional
High Voltage			
Low Voltage			

Wire Identification numbers for Bard (99) use only.
4107-208

WARNING
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
*ELECTRICAL SHOCK HAZARD *DISCONNECT POWER BEFORE SERVICING.

Same Letter Designated Wires Connect if Option Not Used

NOTE: JUMPER PLUG MUST BE INSTALLED WHEN NO VENT OPTION IS INSTALLED (28)