



- EVAPORATOR SECTION :**
 EEV ELECTRONIC EXPANSION VALVE
 STS SUCTION TEMPERATURE SENSOR
 FS FREEZE SENSOR
- BLOWER SECTION :**
 DFS DIRTY FILTER SWITCH
 MAT MIXED AIR TEMPERATURE

- CONDENSER SECTION :**
 SPT SUCTION PRESSURE TRANSDUCER
 HPS HIGH PRESSURE SWITCH
 LPS LOW PRESSURE SWITCH
 OATH OUTDOOR TEMP AND HUMIDITY SENSOR
 RAT RETURN AIR TEMP SENSOR

- CONTROL PANEL :**
 CCM COMPRESSOR CONTROL MODULE
 TB TERMINAL BLOCK

- ECONOMIZER SECTION :**
 DS DAMPER SWITCH

	Factory	Field	Optional
High Voltage	---	---	---
Low Voltage	---	---	---
0-10VDC	---	---	---