



For Vent Wiring or controller/thermostat connections, see literature packet or go to [www.bardhvac.com](http://www.bardhvac.com)

NOTE:  
THIS IS LOCATED  
IN UPPER CONTROL  
PANEL

IF ECONOMIZER IS INSTALLED  
CONNECT HIGH SPEED  
SOLENOID WIRE FROM  
COMPRESSOR TO WIRE  
FROM PIN #1 ON VENT  
PLUG HARNESS

NOTE: JUMPER PLUG MUST BE INSTALLED  
WHEN NO VENT OPTION IS INSTALLED

**WARNING**  
USE COPPER CONDUCTORS  
ONLY SUITABLE FOR AT LEAST  
75° C.

**DANGER**  
\*ELECTRICAL SHOCK HAZARD  
\*DISCONNECT POWER BEFORE  
SERVICING.

**A**  
Wires Connect  
if Option Not  
Used

<sup>99</sup> Wire Identification numbers  
for Bard use only.

	Factory	Field	Optional
High Voltage			
Low Voltage			

4213-332 A