



For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

NOTE: THESE ARE LOCATED IN UPPER CONTROL PANEL ON THE W42-72

BROWN OR BLACK ON W24 MODELS
BLUE OR WHITE ON W24 UNITS

NOTE: W42,48,60 - 50Hz models only: Motor powered with Red (low) lead. Black lead lands on park terminal.

WARNING
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
ELECTRICAL SHOCK HAZARD DISCONNECT POWER BEFORE SERVICING.

Wires Connect if Option Not Used	99 Wire Identification numbers for Bard use only.		
	Factory	Field	Optional
High Voltage			
Low Voltage			

4213-628 A

NOTE: JUMPER PLUG MUST BE INSTALLED WHEN NO VENT OPTION IS INSTALLED

Wire tucked in cable duct if no OD switch (only use with LAC)

Wire tucked in cable duct when no OD switch (only used with LAC)

Low Voltage Box

CLASS 2 Low Voltage Terminal Strip Class 2

12 Pin Plug

Evaporator Section

Condenser Section