

INSTALLATION INSTRUCTIONS

MODELS

18ECQ2	31ECQ2	42ECQ1
18ECS2	31ECS2	42ECS1
24ECQ4	36ECQ5	48ECQ2
24ECS4	36ECS5	48ECS2
30ECQ4	37ECQ1	60ECQ1
30ECS4	37ECS1	60ECS1

SPLIT AIR CONDITIONER
OUTDOOR SECTION

FOR USE WITH:
MATCHING INDOOR BLOWER
COIL UNITS AND MATCHING
ADD ON COIL UNITS ONLY

PARTS LIST
SPLIT SYSTEM CONDENSING UNITS

Date: 7/30/88

Part No.	Description	18ECQ, S2	24BCQ, S4
4021-110	Wiring Diagram	X	X
5051-011	Condenser Coil	X	
5051-013	Condenser Coil		X
5151-001	Fan Blade TF1839	X	X
5651-051	Base Valve*	X	X
5651-053	Base Valve*	X	X
7051-009	Condenser Grille	X	X
7051-010	Wire Grille--Inlet	X	X
8000-061	Compressor RBS3-0175-PFV	X	
8000-071	Compressor AB225HT		X
8103-008	Motor--Fan 1/5 H.P.	X	X
8200-001	Motor Mount--Fan	X	X
8401-007	Contactora--Comp. 25A	X	X
8552-002	Capacitor 5/370V	X	X
8552-007	Capacitor 20/15-370V		X
8552-044	Capacitor 15/10-370V	X	

*Used only on "S" versions.

PARTS LIST
SPLIT SYSTEM CONDENSING UNITS

Page: A1
Date: 7/30/88

Part No.	Description	18ECQ, S2	24ECQ, S4
4021-110	Wiring Diagram	X	X
5051-011	Condenser Coil	X	
5051-013	Condenser Coil		X
5151-001	Fan Blade TF1839	X	X
5651-051	Base Valve*	X	X
5651-053	Base Valve*	X	X
7051-009	Condenser Grille	X	X
7051-010	Wire Grille--Inlet	X	X
8000-061	Compressor RRS3-0175-PFV	X	
8000-071	Compressor AB225HT		X
8103-008	Motor--Fan 1/5 H.P.	X	X
8200-001	Motor Mount--Fan	X	X
8401-007	Contactora--Comp. 25A	X	X
8552-002	Capacitor 5/370V	X	X
8552-007	Capacitor 20/15-370V		X
8552-044	Capacitor 15/10-370V	X	

*Used only on "S" versions.