

REPLACEMENT PARTS MANUAL

BLOWER COIL HEATER PACKAGE

MODELS: EH2BA, EH2BB

Manual 2110-151

Revision B

Date 05-17-95

Supersedes 02-04-91

* GENERAL NOTES *

*Revised and/or additional pages may be issued from time to time.
*A complete and current manual consists of pages dated as shown in the following index.

** INDEX **

<u>Page Description</u>	<u>Page</u>	<u>Date</u>	<u>Supersedes</u>
Functional Components--Exploded View	1	07-11-89	
" " --Usage List	2	05-17-95	02-04-91


*** IMPORTANT ***

Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plate.

BARD MANUFACTURING COMPANY

BRYAN, OHIO 43506

FUNCTIONAL PARTS



Date: 7
Supersedes:

FUNCTIONAL PARTS

Dwg. No.	Part No.	Description	E	E	E	E	E	E
			H	H	H	H	H	H
			2	2	2	2	2	2
			B	B	B	B	B	B
			A	A	A	A	B	B
			A	A	A	A	A	A
			0	0	0	0	0	0
			5	9	5	9	9	9
			N	N	C	C	N	C
1	134-104	Heater Package Base	x	x	x	x	x	x
2	134-106	Heater Package Wrapper	x	x	x	x	x	x
4	8604-092	4.5KW Heat Strip 240V	1		1			
4	8604-093	9KW Heat Strip 240V		1		1	1	1
4	136-145	Fill Plate	x	x	x	x	x	x
5	8201-057	Time Delay Relay H30-75 C1-40	1		1		2	2
5	8201-058	Time Delay Relay H1-30 C45-70		1		1		
6	8607-013	Terminal Block	1	1			1	
8	8615-013	Circuit Breaker 30A (Note A)			1			
8	8615-015	Circuit Breaker 50A (Note A)				1		1
8	8615-037	Circuit Breaker 30A (Note B)			1			
8	8615-040	Circuit Breaker 50A (Note B)				1		1
12	112-214	Circuit Breaker Mounting Plate			x	x		x
13	8402-058	Limit Control L140-3.5	1	2	1	2	2	2
	136-325	Fill Plate (Note B)			1	1		1
	4090-110	Wiring Diagram	x					
	4090-111	Wiring Diagram			x			
	4090-120	Wiring Diagram		x				
	4090-121	Wiring Diagram				x		
	4090-122	Wiring Diagram					x	
	4090-123	Wiring Diagram						x

NOTE A: For units produced prior to date code E95.

NOTE B: For units produced with date code E95 and after.

Date: 5-17-95
Supersedes: 2-04-91

