

REPLACEMENT PARTS MANUAL

BLOWER COIL HEATER PACKAGE MODEL EH3BA

Manual 2110-152

Revision --

Date 7-11-89

Supersedes

* GENERAL NOTES *

*Revised and/or additional pages may be issued from time to time.
*A complete and current manual consists of pages dated as shown in the following index.

** INDEX **


<u>Page Description</u>	<u>Page</u>	<u>Date</u>	<u>Supersedes</u>
Functional Components--Exploded View	1	7-11-89	
" " --Usage List	2	7-11-89	

*** IMPORTANT ***


Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plate.

FUNCTIONAL PARTS

NON-CIRCUIT BREAKER MODELS



CIRCUIT BREAKER MODELS



NOTE: 18 KW HEATER PACKAGES ARE SHOWN. LOWER KW PACKAGES WILL HAVE FEWER PARTS.

Date: 7-11-89
Supersedes:

FUNCTIONAL PARTS

Dwg. No.	Part No.	Description	E H 3 B A A 0 5 N	E H 3 B A A 0 9 N	E H 3 B A A 1 4 N	E H 3 B A A 1 8 N	E H 3 B A A 0 5 C	E H 3 B A A 0 9 C	E H 3 B A A 1 4 C	E H 3 B A A 1 8 C
1	134-104	Heater Package Base	X	X	X	X	X	X	X	X
2	134-103	Heater Package Wrapper	X	X	X	X	X	X	X	X
4	8604-092	4.5KW Heat Strip 240V	1		1		1		1	
4	8604-093	9KW Heat Strip 240V		1	1	2		1	1	2
4	136-142	Fill Plate	X	X			X	X		
5	8201-057	Time Delay Relay H30-75 C1-40	1		1		1		1	
5	8201-058	Time Delay Relay H1-30 C45-70		1	1	1		1	1	1
5	8201-059	Time Delay Relay H30-75 C1-40				1				1
6	8607-013	Terminal Block	1	1					1	1
7	8614-017	Fuse Block			1					
7	8614-018	Fuse Block				1				
8	8615-013	Circuit Breaker 30A					1		1	
8	8615-015	Circuit Breaker 50A						1	1	2
9	8614-006	Fuse 30A			2					
9	8614-005	Fuse 50A			2	4				
	4090-110	Wiring Diagram	X							
	4090-111	Wiring Diagram					X			
	4090-120	Wiring Diagram		X						
	4090-121	Wiring Diagram						X		
	4090-130	Wiring Diagram			X					
	4090-131	Wiring Diagram							X	
	4090-140	Wiring Diagram				X				
	4090-141	Wiring Diagram								X
10	134-105	Fusing Barrier			X	X				
11	112-093	Circuit Breaker Mounting Plate							X	X
12	112-092	Circuit Breaker Mounting Plate					X	X	X	X
13	8402-056	Limit Control L150-3.5	1	2	3	4	1	2	3	4

Date: 7-11-89
Supersedes: