
WALL MOUNT HEATER PACKAGE

REPLACEMENT PARTS MANUAL

Models:

EHWA02-A05B	EHWA02A-A08B
EHWA02A-A05LB	EHW02A-A08LB
EHWA02A-A10B	EHWA02-A10LB
EHWH02A-A04B	EHWH02A-A08B
EHWA24A-A04B	EHWA24-B06B
EHWA24-B06LB	EHW24H-A04B
EHW24H-A08B	EHW24H-B06B
EHWH24B-C06	EHWH24B-C06L
EHW02A-A08B	EHWH02-A05B
EHWH24-B06	EHWH02ALA04B

General Notes

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

Contents

Description	Page
Functional Components	
♦ Exploded View	2
♦ Usage List	3
♦ Usage List	4




Climate Control Solutions

Bard Manufacturing Company, Inc.
Bryan, Ohio 43506
Since 1914...Moving ahead, just as planned.

Manual: 2110-620D
Supersedes: 2110-620C
File: Tab 18
Date: 08-25-14

FUNCTIONAL COMPONENTS



SEXP-173

Reference this Drawing for Pages 3 & 4

FUNCTIONAL COMPONENTS

Drawing No.	Part No.	Description	EHWH02ALA-A04B	EHWH02-A05B	EHWA02-A05B	EHWA02A-A08B	EHWA02A-A10B	EHWA24-B06B	EHW24H-A04B	EHW24H-A08B	EHW24H-B06B	EHWH24B-C06	EHWA24A-A04B	EHWH02A-A04B	EHWH02A-A08B	EHW02A-A08B	EHWH24-B06
1	8604-089	Heat Strip 5 KW		X	X												
1	8604-095	Heat Strip 10 KW				X											
1	8604-090	Heat Strip 8 KW				X			X						X	X	
1	8604-049	Heat Strip 6 KW						X			X						X
1	8604-088	Heat Strip 4 KW	X						X				X	X			
1	8604-100	Heat Strip 6 KW										X					X
2	127X210	Heater Control Base	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
2	127-321	Heater Control Base										X					
3	8402-065	Limit Control Device		X	X		X	X			X	X					X
3	8402-049	Limit Control Device	X						X				X	X			
3	8402-074	Limit Control Device				X			X						X	X	
4	8402-091	Thermal Cutoff						2			2						2
4	8402-114	Thermal Cutoff	X	X	X				X				X	X			
4	8402-094	Thermal Cutoff										2					
4	8402-093	Thermal Cutoff				2	2			2					2	2	
5	8615-036	Circuit Breaker 25A	X						X				X				
5	8615-067	Disconnect Switch										X					
5	8615-037	Circuit Breaker 30A			X												
5	8615-041	Circuit Breaker 60A					X								X		
5	8615-042	Circuit Breaker 35A 3PH															X
5	8615-055	Circuit Breaker 40A									X			X			
5	8615-039	Circuit Breaker 45A		X		X			X	X							
5	8615-051	Circuit Breaker 25A						X									
5	8615-040	Circuit Breaker 50A														X	
5	8615-043	Circuit Breaker 40A															
6	8401-006	Heater Contactor	X	X	X				X	2			X	X			
6	8401-002	Heater Contactor						X			X	X					X
6	8401-025	Heater Contactor				X	X								X	X	
NS	4097-121	Wiring Diagram	X	X					X					X			
NS	4097-140	Wiring Diagram				X	X									X	
NS	4097-220	Wiring Diagram						X									
NS	4097-221	Wiring Diagram									X						X
NS	4097-120	Wiring Diagram			X								X				
NS	4097-322	Wiring Diagram										X					
NS	4097-141	Wiring Diagram							X								
NS	4097-131	Wiring Diagram												X			

NS = Not Shown

FUNCTIONAL COMPONENTS

Drawing No.	Part No.	Description	EHWA02-A10LB	EHWA24-B06LB	EHWA02A-A05LB	EHW02A-A08LB	EHWH24-C06L
1	8604-095	Heat Strip 10 KW	X			X	
1	8604-090	Heat Strip 8 KW		X			
1	8604-049	Heat Strip 6 KW		X			
1	8604-089	Heat Strip 5 KW			X		
1	8604-100	Heat Strip 6 KW					X
2	127Y210	Heater Control Base	X	X	X	X	
2	127-211	Heater Control Base					X
3	8402-065	Limit Control	X	X		X	X
3	8402-081	Limit Control			X		
4	8402-114	Thermal Cutoff			X		
4	8402-093	Thermal Cutoff	2	2		2	
4	8402-094	Thermal Cutoff					X
5	8615-037	Circuit Breaker 30A			X		
5	8615-041	Circuit Breaker 60A	X			X	
5	8615-039	Circuit Breaker 45A					
5	8615-051	Circuit Breaker 25A		X			
5	8615-053	Pull Disconnect					X
6	8401-006	Heat Contactor			X		
6	8401-002	Heat Contactor		X			X
6	8401-025	Heat Contactor	X			X	
NS	4097-140	Wiring Diagram	X			X	
NS	4097-220	Wiring Diagram		X			
NS	4097-120	Wiring Diagram			X		
NS	4097-322	Wiring Diagram					X

NS – Not Shown