

---

# REPLACEMENT PARTS MANUAL

---

## WALL MOUNT HEATER PACKAGE

Models:

EHW2TA-A05	EHW2TH-A08	EHW24A-A08	EHWA24-B06B
EHW2TA-A05L	EHWA02-A05B	EHW24H-A08B	EHW24H-A04B
EHW2TA-A08	EHWA02A-A05LB	EHWH24B-C06	EHW24H-B06B
EHW2TA-A08L	EHWA02A-A10B	EHW02A-A08B	EHWH24B-C06L
EHW2TA-A10	EHWH02A-A04B	EHWH24-B06	EHWH02-A05B
EHW2TA-A10L	EHWA24A-A04B	EHWA02A-A08B	EHWH02ALA04B
EHW2TA-B06	EHWA24-B06LB	EHW02A-A08LB	
EHW2TA-B06L	EHW18H-A04	EHWA02-A10LB	
EHW2TH-A04	EHW18H-A08	EHWH02A-A08B	

---

### General Notes

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

### Important

- Contact the installing and/or local Bard distributor for all parts requirements. Make sure to have the complete model and serial number available from the unit rating plates.

### Contents

Description	Page
Functional Components	
♦ Layout View .....	2
♦ Usage List .....	3
♦ Usage List .....	4




Bard Manufacturing Company, Inc.  
Bryan, Ohio 43506  
www.bardhvac.com

Manual: 2110-620F  
Supersedes: 2110-620E  
Date: 12-17-15

# FUNCTIONAL COMPONENTS

---



SEXP-173

Reference this drawing for pages 3 and 4

# FUNCTIONAL COMPONENTS

Drawing No.	Part No.	Description	EHWH02ALA04B	EHWH02-A05B	EHWA02-A05B	EHWA02A-A08B	EHWA02A-A10B	EHWA24-B06B	EHW24H-A04B	EHW24H-A08B	EHW24H-B06B	EHWH24B-C06	EHWA24A-A04B	EHWH02A-A04B	EHWH02A-A08B	EHW02A-A08B	EHWH24-B06	EHW2TA-A05	EHW24A-A08	EHW2TA-A10	EHW2TA-B06	EHW2TH-A04	EHW2TH-A08	EHW18H-A04	EHW18H-A08	EHW2TA-A08
1	8604-089	Heat Strip 5 KW		X	X													X								
1	8604-095	Heat Strip 10 KW				X									X	X			X							
1	8604-090	Heat Strip 8 KW				X			X						X	X			X				X		X	X
1	8604-049	Heat Strip 6 KW					X			X							X			X						
1	8604-088	Heat Strip 4 KW	X					X					X	X							X		X			
1	8604-100	Heat Strip 6 KW										X														
2	127X210	Heater Control Base	X	X	X	X	X	X	X	X	X		X	X	X	X	X	X	X	X	X	X	X	X	X	X
2	127-321	Heater Control Base										X														
3	8402-065	Limit Control Device		X	X		X	X			X	X					X				X					
3	8402-049	Limit Control Device	X					X					X	X								X		X		
3	8402-074	Limit Control Device				X			X						X											
3	8402-031	Limit Control Device																	X						X	
3	8402-082	Limit Control Device																X								
3	8402-119	Limit Control Device																		X						
3	8402-074	Limit Control Device																				X		X		
4	8402-091	Thermal Cutoff					2			2							2									
4	8402-114	Thermal Cutoff	X	X	X			X					X	X												
4	8402-096	Thermal Cutoff																					2		2	
4	8402-094	Thermal Cutoff										2														
4	8402-093	Thermal Cutoff				2	2			2					2	2										2
4	8402-092	Thermal Cutoff															X		2	2	2	X	X			
5	8615-036	Circuit Breaker 25A	X						X			X	X										X			
5	8615-067	Disconnect Switch									X								X							
5	8615-037	Circuit Breaker 30A			X														X							
5	8615-041	Circuit Breaker 60A				X								X						X					X	
5	8615-042	Circuit Breaker 35A 3PH																		X						
5	8615-055	Circuit Breaker 40A									X			X									X			
5	8615-039	Circuit Breaker 45A		X		X		X	X					X						X		X	X			
5	8615-051	Circuit Breaker 25A					X														X					
5	8615-040	Circuit Breaker 50A													X											X
5	8615-043	Circuit Breaker 40A																								
6	8401-006	Heater Contactor	X	X	X			X	2				X	X					X			X	2	X		
6	8401-002	Heater Contactor					X				X	X									X					
6	8401-025	Heater Contactor				X	X								X	X			X	X					X	X
NS	4097-121	Wiring Diagram	X	X				X						X								X		X		
NS	4097-140	Wiring Diagram				X	X									X			X	X						X
NS	4097-220	Wiring Diagram					X														X					
NS	4097-221	Wiring Diagram						X									X									
NS	4097-120	Wiring Diagram			X								X						X							
NS	4097-322	Wiring Diagram										X		X												
NS	4097-141	Wiring Diagram						X															X			
NS	4097-131	Wiring Diagram													X										X	

NS = Not Shown

# FUNCTIONAL COMPONENTS

Drawing No.	Part No.	Description	EHWA02-A10LB	EHWA24-B06LB	EHWA02A-A05LB	EHW02A-A08LB	EHWH24-C06L	EHW2TA-A05L	EHW2TA-A10L	EHW2TA-B06L	EHW2TA-A08L
1	8604-095	Heat Strip 10 KW	X			X			X		
1	8604-090	Heat Strip 8 KW									X
1	8604-049	Heat Strip 6 KW		X						X	
1	8604-089	Heat Strip 5 KW			X			X			
1	8604-100	Heat Strip 6 KW					X				
2	127Y210	Heater Control Base	X	X	X	X		X	X	X	X
2	127-211	Heater Control Base					X				
3	8402-065	Limit Control	X	X		X	X			X	
3	8402-081	Limit Control			X						
3	8402-031	Limit Control									X
3	8402-082	Limit Control						X			
3	8402-119	Limit Control							X		
4	8402-114	Thermal Cutoff			X						
4	8402-093	Thermal Cutoff	2	2		2					2
4	8402-094	Thermal Cutoff					X				
4	8402-092	Thermal Cutoff						X	2	2	
5	8615-037	Circuit Breaker 30A			X			X			
5	8615-041	Circuit Breaker 60A	X			X			X		
5	8615-039	Circuit Breaker 45A									
5	8615-040	Circuit Breaker 50A									X
5	8615-051	Circuit Breaker 25A		X						X	
5	8615-053	Pull Disconnect					X				
6	8401-006	Heat Contactor			X			X			
6	8401-002	Heat Contactor		X			X			X	
6	8401-025	Heat Contactor	X			X			X		X
NS	4097-140	Wiring Diagram	X			X			X		X
NS	4097-220	Wiring Diagram		X						X	
NS	4097-120	Wiring Diagram			X			X			
NS	4097-322	Wiring Diagram					X				

NS – Not Shown