# Replacement Parts Manual

## COMMERCIAL ROOM VENTILATOR

**MODEL: QCRV-4** 

#### **General Notes**

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

#### **Contents**

Description	Page
Functional &Cabinet Components	
Exploded View	1
Usage List	

2110-667A

10-15-97

Vol II Tab 14


Manual:

File:

Date:

### **Important**

Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plates.



### **FUNCTIONAL and CABINET COMPONENTS**

Drawing			QCRV-4
No.	Part No.	Part No. Description	3
1	137-370	Front Fill	X
2	100Y346	Left End	X
3	139-116	Blade	X
4	137-369	Rear Fill	X
5	127-279	Base	X
6	8602-040	Bracket	X
7	8602-038	Damper Blade Pin	X
8	8602-039	Bushing	Χ
9	100X346	Right End	X
10	8602-044	Rod	X
11	8602-008	Ball Joint	X
12	8602-020	Motor	X
NS	3000-1072	Wire Assembly	X
NS	4056-132	Wiring Diagram	X