

---

# Replacement Parts Manual

# MASTER CONTROLLER

Models:

# MC95HAE

---

## General Notes

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

## Contents

Description	Page
Functional and Cabinet Components	
♦ Exploded View .....	1
♦ Usage List .....	2




**BARD MANUFACTURING COMPANY**  
Bryan, Ohio 43506

*Since 1914...Moving ahead, just as planned.*

Manual: 2110-672  
Supersedes: Rev.  
Date: 07-30-97

# FUNCTIONAL and CABINET COMPONENTS



SEXP-274

# FUNCTIONAL and CABINET COMPONENTS

---

Drawing No.	Part No.	Description	MC95HAE
1	127-209-X	Base	X
2	141-186-X	Thermostat Mounting Base	X
3	8404-013	Subbase	X
4	8403-031	Thermostat	X
5	8407-041	Transformer	X
6	8408-021	Low Alarm Thermostat	X
7	8408-022	High Alarm Thermostat	X
8	8607-010	Terminal Strip (13 position)	X
9	8201-048	Switching Relay	6
10	8612-014	24 Hour and 7 Day Recycle Timer	X
11	8607-011	Terminal Strip (10 position)	X
12	8201-062	Relays	5
13	8406-082	Timer Speedup Switch	X
14	8604-013	Terminal Block	X
15	117-136-X	High Voltage Box	X
16	141-187-X	Mounting Bracket	X
NS	4093-129	Wiring Diagram	X

NS = Not Shown