
Replacement Parts Manual

MASTER CONTROLLER

Model:

MC95HAE-1

General Notes

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

Contents

Description	Page
Functional and Cabinet Components	
♦ Exploded View	1
♦ Usage List	2




BARD MANUFACTURING COMPANY
Bryan, Ohio 43506

Since 1914...Moving ahead, just as planned.

Manual: 2110-675
Supersedes:
Date: 12-16-99

FUNCTIONAL and CABINET COMPONENTS



SEXP-274

FUNCTIONAL and CABINET COMPONENTS

Drawing No.	Part No.	Description	MC95HAE-1
1	127-209-X	Base	X
2	141-186-X	Thermostat Mounting Base	X
3	8404-013	Subbase	X
4	8403-031	Thermostat	X
5	8407-041	Transformer	X
6	8408-021	Low Alarm Thermostat	X
7	8408-022	High Alarm Thermostat	X
8	8607-010	Terminal Strip (13 position)	X
9	8201-048	Switching Relay	4
10	8612-014	24 Hour and 7 Day Recycle Timer	X
11	8607-011	Terminal Strip (10 position)	X
12	8201-062	Relays	5
13	8406-082	Timer Speedup Switch	X
14	8604-013	Terminal Block	X
15	117-136-X	High Voltage Box	X
16	141-187-X	Mounting Bracket	X
17	8201-071	Switching Relay	2
NS	4093-129	Wiring Diagram	X

NS = Not Shown