

# REPLACEMENT PARTS MANUAL

## HIGH EFFICIENCY GAS FURNACE

MODELS: DCL065D36A, DCL080D48A,  
DCL095D60A, DCL110D60A

Manual 2110-867

Revision E

Date 05-02-95

Supersedes 03-29-95

\*\*\*\*\*  
\* GENERAL NOTES \*  
\*\*\*\*\*

\*Revised and/or additional pages may be issued from time to time.  
\*A complete and current manual consists of pages dated as shown in the following index.


\*\*\*\*\*  
\*\* INDEX \*\*  
\*\*\*\*\*

<u>Page</u>	<u>Description</u>	<u>Page</u>	<u>Date</u>	<u>Supersedes</u>
Cabinet	Components--Exploded View	1	<b>02-01-94</b>	
	"	2	<b>12-15-94</b>	<b>02-01-94</b>
	--Usage List	3	<b>12-15-94</b>	<b>02-01-94</b>
	--Usage List	3	<b>12-15-94</b>	<b>02-01-94</b>
Functional	Components--Exploded View	4	<b>07-18-94</b>	<b>02-01-94</b>
	"	5	<b>05-02-95</b>	<b>03-29-95</b>
	--Usage List	5	<b>05-02-95</b>	<b>03-29-95</b>
Control	Panel Wire Assemblies--Exploded View	6	<b>02-01-94</b>	
	"	7	<b>02-24-95</b>	<b>07-18-94</b>
	--Usage List	7	<b>02-24-95</b>	<b>07-18-94</b>

\*\*\*\*\*  
\*\*\* IMPORTANT \*\*\*  
\*\*\*\*\*

Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plate.

CABINET COMPONENTS



DC1080/095 MODEL SHOWN

Date: 02-01-94  
Supersedes:

2110-867  
Page: 1

CABINET COMPONENTS

Dwg. No.	Part No.	Description	D C L O 6 5 D 3 6 A	D C L O 8 0 D 4 8 A	D C L O 9 5 D 6 0 A	D C L I 1 O D 6 O A
1	S126-232	Base Assembly	x			
1	S126-233	Base Assembly		x	x	
1	S126-234	Base Assembly				x
2	104-917	Front Base Angle	x			
2	104-918	Front Base Angle		x	x	
2	104-919	Front Base Angle				x
3	168-050	Secondary Air Restrictor	x			
3	168-055	Secondary Air Restrictor		x	x	
3	168-060	Secondary Air Restrictor				x
4	104-920	Rear Base Angle	x			
4	104-921	Rear Base Angle		x	x	
4	104-922	Rear Base Angle				x
5	520-227	Coil Partition Assembly	x	x	x	x
6	500-283	Left Side Assembly	x	x	x	x
7	S104-889	Left Side Angle	x	x	x	x
8	S120-270	Internal Coil Partition	x	x	x	x
9	134-142	Coil Air Deflector	x	x	x	x
10	116-130	Junction Box	x	x	x	x
11	132-107	Junction Box Cover	x	x	x	x
12	104-934	Side Top Support Angle	x	x	x	x
13	S168-052	Burner Box Cover	x			
13	S168-058	Burner Box Cover		x	x	
13	S168-063	Burner Box Cover				x
14	S552-233	Blower Door Assembly	x			
14	S552-234	Blower Door Assembly		x	x	
14	S552-235	Blower Door Assembly				x
15	104Y925	Left Blower Angle			x	x
15	104Y926	Left Blower Angle	x	x		
16	108-104	Upper Back	x			
16	108-105	Upper Back		x	x	
16	108-106	Upper Back				x
17	116-166	Control Panel Plug Support	x	x	x	x
18	132-123	Control Panel Cover	x	x	x	x
19	116-161	Control Panel	x			
19	116-160	Control Panel		x	x	
19	116-163	Control Panel				x
20	116-164	Control Panel Support	2	2	2	2
21	104-936	Filter Support Angle	x			
21	104-935	Filter Support Angle		x	x	
21	104-937	Filter Support Angle				x
22	S136-272	Internal Coil Fill	x	x	x	x


Date: 12-15-94  
Supersedes: 02-01-94

CABINET COMPONENTS

Dwg. No.	Part No.	Description	D C L O 6 5 D 3 6 A	D C L O 8 0 D 4 8 A	D C L O 9 5 D 6 0 A	D C L 1 1 0 D 6 0 A
23	164-545	Top Channel	x			
23	164-546	Top Channel		x	x	
23	164-547	Top Channel				x
24	S152-209	Vestibule Door	x			
24	S152-216	Vestibule Door		x	x	
24	S152-217	Vestibule Door				x
25	520-261	Blower Partition Assembly	x			
25	520-262	Blower Partition Assembly		x	x	
25	520-263	Blower Partition Assembly				x
26	500-282	Right Side Assembly	x	x	x	x
27	S106-152	Top Fill Assembly	x			
27	S106-151	Top Fill Assembly		x	x	
27	S106-153	Top Fill Assembly				x
28	104-895	Top Fill Angle	x			
28	104-896	Top Fill Angle		x	x	
28	104-897	Top Fill Angle				x
29	168-002	Internal Flue Baffle	2	3	3	2
30	134-121	Intake Air Shield	x			
31	168-013	Internal Flue Baffle				2
32	134-120	Vent Air Shield	x	x	x	x
33	S168-054	Collector Box Assembly	x			
33	S168-081	Collector Box Assembly		x	x	
33	S168-064	Collector Box Assembly				x
34	S104-903	Right Side Angle	x	x	x	x
35	171-216	Heat Exchanger Assembly	x			
35	171-217	Heat Exchanger Assembly		x	x	
35	171-218	Heat Exchanger Assembly				x
36	112-147	Ignitor Bracket	x	x	x	x
37	913-0066	Burner Box Assembly	x			
37	913-0067	Burner Box Assembly		x	x	
37	913-0070	Burner Box Assembly				x
38	104X925	Right Blower Angle			x	x
38	104X926	Right Blower Angle	x	x		

Date: 12-15-94  
Supersedes: 02-01-94

FUNCTIONAL COMPONENTS



DC1080/095 MODEL SHOWN

Date: 07-18-94  
Supersedes: 02-01-94

2110-867  
Page: 4


FUNCTIONAL COMPONENTS

Dwg. No.	Part No.	Description	D C L O 6 5 D 3 6 A	D C L O 8 0 D 4 8 A	D C L O 9 5 D 6 0 A	D C L 1 1 0 D 6 0 A
1	8611-074	Double Terminal Bushing	x	x	x	x
2	8611-073	Single Terminal Bushing	x	x	x	x
3	6093-007	No-Hub Connector	x	x	x	x
4	8406-069	Pressure Switch	x			
4	8406-070	Pressure Switch		x	x	x
5	5055-004	Coil Assembly		x		
5	5055-003	Coil Assembly	x		x	x
6	S8611-089	Plastic Wire Channel	x	x	x	x
7	3000-1014	Wire Harness	x	x	x	x
8	8552-002	Capacitor 5 MFD 370V	x			
8	8552-004	Capacitor 7-1/2 MFD 370V		x		
8	8552-026	Capacitor 15 MFD 370V			x	
8	8552-034	Capacitor 15 MFD 440V				x
9	8105-041	1/3 HP Motor 115V	x			
9	8106-033	1/2 HP Motor 115V		x		
9	8107-007	3/4 HP Motor 115V			x	
9	8107-008	3/4 HP Motor 115V				x
10	8200-033	Motor Mount Band	x	x	x	x
11	8200-034	Motor Mount Arm	x	x		
11	8200-035	Motor Mount Arm			x	x
12	5152-013	Blower Wheel	x			
12	5152-059	Blower Wheel		x		
12	5152-053	Blower Wheel			x	
12	5152-072	Blower Wheel				x
12	5152-073	Blower Wheel				x
13	151-085	Blower Housing	x			
13	151-082	Blower Housing		x		
13	5152-050	Blower Housing (1)			x	
13	151-102	Left Blower Housing				x
13	151-103	Right Blower Housing				x
14	8406-047	Door Switch	x	x	x	x
15	8611-075	Sight Glass	x	x	x	x
16	8407-039	Transformer 40VA	x	x	x	x
17	5651-124	Furnace Control	x	x	x	x
18	1171-025	Door Pull	x	x	x	x
19	7003-023	9.5 x 20 Permanent Filter	2			
19	7003-016	13 x 20 Permanent Filter		1	1	2
20	7003-021	10 x 20 Permanent Filter		1	1	
21	6095-006	High Temperature Elbow	x	x	x	x
22	5452-005-6000	Vinyl Drain Hose	x	x	x	x

(1) Drawing No. 13 part No.5152-050 includes housing, diffuser, and wheel part No. 5152-053.

Date: 05-02-95  
Supersedes: 03-29-95

CONTROL PANEL WIRE ASSEMBLIES



Date: 02-01-94  
Supersedes:

2110-867  
Page: 6

FUNCTIONAL COMPONENTS AND CONTROL PANEL WIRE ASSEMBLIES

Dwg. No.	Part No.	Description	D	D	D	D
			C	C	C	C
			L	L	L	L
			0	0	0	1
			6	8	9	1
			5	0	5	0
			D	D	D	D
			3	4	6	6
			6	8	0	0
			A	A	A	A
23	7002-023	Bird Screen 2.875 Diameter	2			
24	7002-022	Bird Screen 2.375 Diameter	2			
25	7002-024	Bird Screen 3.500 Diameter	2	2	2	
25	7002-025	Bird Screen 4.500 Diameter				2
26	8620-084	Induced Draft Blower	x	x	x	x
27	8402-089	Limit 230 degree F	x			
27	8402-078	Limit 175 degree F		x	x	x
28	8553-003	Ignitor	x	x	x	x
29	9010-070	Burner 2 cell	x			
29	9010-071	Burner 3 cell		x	x	
29	9010-072	Burner 4 cell				x
30	5651-083	Gas Valve	x			
30	5651-089	Gas Valve		x	x	
30	5651-106	Gas Valve				x
31	5451-017	Manifold Grommet	x	x	x	x
32	8554-016	Sensor	x	x	x	x
33	9010-043	Gas Orifice #36	2			
33	9010-057	Gas Orifice 2.45MM		3		
33	9010-052	Gas Orifice 2.70MM			3	
33	9010-010	Gas Orifice #38				4
34	S112X194	Right Manifold Bracket	x	x	x	x
35	5818-028	Gas Manifold	x			
35	5818-029	Gas Manifold		x	x	
35	5818-030	Gas Manifold				x
36	S112Y194	Left Manifold Bracket	x	x	x	x
37	3000-1019	4 Pin Wire Assembly	x	x	x	x
38	3000-1018	5 Pin Wire Assembly	x	x	x	x
39	3000-1016	3 Pin Wire Assembly	x	x	x	x
40	3000-1013	12 Pin Wire Assembly	x	x	x	x
41	6095-005	2" PVC Street Elbow	x	x	x	
41	6095-008	2" ABS Street Elbow				x
42	144-127	Diffuser	x			
42	144-129	Diffuser		x		
42	(1) N/A	Diffuser			x	
42	144-167	Diffuser				x

(1) Drawing No. 13 part No. 5152-050 includes diffuser.

Date: 02-24-95  
Supersedes: 07-18-94

2110-867  
Page: 7