

4 H.P.S = Green fault light illuminated when fault indicated.
5 L.P.S = Orange fault light illuminated when fault indicated.
6 F.S = Red fault light illuminated when fault indicated.
7 COND. = Yellow fault light illuminated when fault indicated.
8 Status = Green Status LED will blink in normal operation.