


CURRENT SENSING RELAYS

C.S.R. #1 - Compressor

C.S.R. #3 - Indoor Motor



Neutral (Earth)

Compressor Motor Signal Light 115 VAC

Indoor Motor Signal Light 115 VAC

240/220-50-1


USE COPPER OR ALUMINUM WIRE

Model 18WA1 w/4kw


CURRENT SENSING RELAYS

CSR #1 - Compressor

CSR #3 - Indoor Motor



T87F or Equivalent Thermostat



24V Terminal Block

Limit



Yellow Transformer

Heater Contactor

Status-Alarm Terminal Block

Neutral

Equipment Ground




USE COPPER OR ALUMINUM WIRE

Factory Wiring
Field Wiring

MODEL 24WA-BL19
w/4.5Kv

4007-801 Rev. C

415/380-50-3




USE COPPER OR ALUMINUM WIRE

- ⚠ 1-terminal capacitor provides off-cycle crankcase heat.
- ⚠ This wire omitted and 2-terminal capacitor used on model 18WA1 and 20WA.
- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A

Models
18WA1, 20WA, 24WA1
w/4 or 5Kw

ory Wiring ———
ield Wiring - - - -




USE COPPER OR ALUMINUM WIRE

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet. Set heat anticipator at .40A.

230/208-60-1

MODELS
20WA1 & 24WA2
w/4 or 5Kw

Factory Wiring _____
Field Wiring - - - - -




USE COPPER OR ALUMINUM WIRE

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet. Set heat anticipator at .40A.

230/208-60-1

MODELS
20WA1 & 24WA2
w/4 or 5kw

Factory Wiring ———
Field Wiring - - - - -



USE COPPER OR ALUMINUM WIRE

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet. Set heat anticipator at .40A.


230/208-60-1

MODELS
20WA1 & 24WA2
w/4 or 5Kw

Factory Wiring ———
Field Wiring - - - - -

4007-803D

100-14 300 520




USE COPPER OR ALUMINUM WIRE

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet. Set heat anticipator at .40A.

230/208-60-1

MODELS
20WA1 & 24WA2
w/4 or 5kw

Factory Wiring ———
Field Wiring - - - - -



USE COPPER OR ALUMINUM WIRE


- ⚠️ 1 Capacitor provides off-cycle crankcase heat.
- ⚠️ 2 See alternate thermostat sheet. Set heat anticipator at .40A.

Fused Disconnect Switch

230/208-60-1

MODELS
20WA1 & 24WA2
w/4 or 5kw

Factory Wiring _____
Field Wiring - - - - -




- ⚠ 3-terminal capacitor provides off-cycle crankcase heat.
- ⚠ This wire omitted and 2-terminal capacitor used on model 18WA1 and 20WA.
- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A


Models
18WA1, 20WA, 24WA1
w/4 or 5kw

ory Wiring ———
ad Wiring - - - - -

CURRENT SENSING RELAYS

- C.S.R. #1 - Compressor
- C.S.R. #2 - Outdoor Motor
- C.S.R. #3 - Indoor Motor






- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet.
- 3 For 208V operation move this wire to 208V transformer tap.

MODELS
20WA1 & 24WA2

Factory Wiring _____
Field Wiring - - - - -



Equip. Ground

USE COPPER CONDUCTORS ONLY

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet.

Fused Disconnect Switch


230/208-60-1

REVISED DIAGRAM
REPLACES
4007-205A
DATE 9-9-5-

MODELS
20WA1 & 24WA2

Factory Wiring _____
Field Wiring - - - - -

4007-803 B



USE COPPER CONDUCTORS ONLY


- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet.

230/208-50-1

MODELS
20WA1 & 24WA2


Factory Wiring _____
Field Wiring - - - - -

4007-805A




USE COPPER CONDUCTORS ONLY

- ⚠ 1 3-terminal capacitor provides off-cycle heat.
- ⚠ 2 This wire omitted and 2-terminal capacitor used on models 18WA1 and 20WA.
- ⚠ 3 See alternate thermostat sheet.



Models
18WA1, 20WA, 24WA1

Factory Wiring _____
Field Wiring - - - - -




USE COPPER OR ALUMINUM WIRE

- ⚠ 1 3-terminal capacitor provides off-cycle crankcase heat.
- ⚠ 2 This wire omitted and 2-terminal capacitor used on model 18WA1 and 20WA.
- ⚠ 3 See alternate thermostat sheet. Set heat anticipator at .40A for W1 and W2.
- ⚠ 4 Add jumper Rc to Rh.

Models
18WA1, 20WA, 24WA1
w/8 or 10Kw

Factory Wiring ———
Field Wiring - - - - -




USE COPPER OR ALUMINUM WIRE

- 1 Capacitor provides off-cycle crankcase heat.
- 2 See alternate thermostat sheet. Set heat anticipator at .40A.
- 3 For 208V operation move this wire to 208V transformer tap.

230/208-60-1

**MODELS
20WA1 & 24WA2
w/4 or 5kw**

Factory Wiring ———
Field Wiring - - - - -



T872C1004 Thermostat
 Q672A1005 Subbase
 or
 T874C1000 Thermostat
 Q674A1001 Subbase

USE COPPER OR ALUMINUM WIRE


- ⚠ Capacitor provides off-cycle crankcase heat.
- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer tap.

Fused Disconnect Switch


230/208-60-1

Models
 20WA1 & 24WA2
 w/8 or 10Kw

Factory Wiring _____
 Field Wiring - - - - -




Factory Wiring _____
Field Wiring - - - - -



USE COPPER OR ALUMINUM WIRE


- ⚠ Capacitor provides off-cycle crankcase heat.
- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.



230/208-60-1

Models
20WA1 & 24WA2
w/8 or 10KW

Factory Wiring ———
Field Wiring - - - - -



USE COPPER OR ALUMINUM WIRE


- ⚠️ Capacitor provides off-cycle crankcase heat.
- ⚠️ See alternate thermostat sheet. Set heat anticipator at .40A.

Fused Disconnect Switch

230/208-60-1

Models
20WA1 & 24WA2
w/8 or 10Kw

Factory Wiring ———
Field Wiring - - - - -



TB72C1004 Thermostat
 Q672A1005 Subbase
 or
 TB74C1000 Thermostat
 Q674A1001 Subbase

NEC Class 2
 24V Wiring

24V
 Terminal
 Block

240V Terminal Block

USE COPPER OR
 ALUMINUM WIRE


- ⚠ Capacitor provides off-cycle crankcase heat.
- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.

Fused
 Disconnect
 Switch

230/208-60-1

Models
 20WA1 & 24WA2
 w/8 or 10Kw

Factory Wiring ———
 Field Wiring - - - - -



USE COPPER OR ALUMINUM WIRE

- ⚠ 1 3-terminal capacitor provides off-cycle crankcase heat.
- ⚠ 2 This wire omitted and 2-terminal capacitor used on model 18WA1 and 20WA.
- ⚠ 3 See alternate thermostat sheet. Set heat anticipator at .40A for W1 and W2.
- ⚠ 4 Add jumper Rc to Rh.


Fused Disconnect Switch

230V 60Hz 1-Ph

Models
18WA1, 20WA, 24WA1
w/8 or 10kw

Post-it® Fax Note	7671	Date	1/20/00	# of pages	1
To	BRAD	From			
Co./Dept.		Co.	BARD MFG CO		
Phone #	360-855-3509	Phone #			
Fax #		Fax #			

Factory Wiring
Field Wiring



USE COPPER OR ALUMINUM WIRE

- ⚠ 1 3-terminal capacitor provides off-cycle crankcase heat.
- ⚠ 2 This wire omitted and 2-terminal capacitor used on model 18WA1 and 20WA.
- ⚠ 3 See alternate thermostat sheet. Set heat anticipator at .40A.

230V 60Hz 1-Ph

Models
18WA1, 20WA, 24WA1
w/8 or 10kw

Factory Wiring ———
Field Wiring - - - - -