


INSTALLATION INSTRUCTIONS

SELF CONTAINED WALL MOUNTED
HEAT PUMPS



18WH1

20WH

24WH1


30WH

36WH1


48WH1

APPLICATIONS


RESIDENTIAL . . . single, multiple, mobile




Zoned heating/cooling control in multiple areas



Attic ducted single unit installation




Multiple dwelling installation




Offices/Homes on wheels


COMMERCIAL and INSTITUTIONAL




Separate offices (zoned)



Production areas (for complete conditioning from single unit)



Churches (zoned)



Temporary classrooms

ELECTRICAL INFORMATION										WIRING INFORMATION**					
Model	Rated Volts & Ph	Operating Voltage Range	Heater* Kw	Max Unit Amps	No. Field Power Circuits	Internal Fuses		Req'd Ext. Fuses		Min. Ckt. Ampacity	Field Power Wiring		Ground Wire Size	Wiring Diagram Number	
						Ckt.A	Ckt.B	Ckt.A	Ckt.B		Ckt.A	Ckt.B			Ckt.A
18WH1	230/1	197-253	0	13.8	1			25		17	12	12	12	4011-110B	
18WH1	230/1	197-253	4	30.5	1			40		38	8	10	10	-120B	
18WH1	230/1	197-253	8	47.1	2			40	25	38	6	10	10	-130B	
20WH	230/1	197-253	0	14.3	1			25		17	12	12	12	4011-110B	
20WH	230/1	197-253	4	31	1			45		38	8	10	10	-120B	
20WH	230/1	197-253	8	47.6	2			45	25	38	6	10	10	-130B	
24WH1	230/1	197-253	0	15.8	1			30		19	12	12	12	4011-110B	
24WH1	230/1	197-253	4	32.5	1			45		40	8	10	10	-120B	
24WH1	230/1	197-253	8	49.1	2			45	25	40	6	10	10	-130B	
30WH	230/1	197-253	0	18.8	1			35		22	10	10	10	4012-110C	
30WH	230/1	197-253	5	39.6	1			50		48	6	10	10	-120B	
30WH	230/1	197-253	10	60.4	2			50	30	48	4	10	10	-130B	
30WH	230/1	197-253	15	65.9	2	50	60	50	60	48	4	10	10	-140B	
36WH1	230/1	197-253	0	27.5	1			50		33	8	10	10	4013-110B	
36WH1	230/1	197-253	5	48.3	1			60		59	4	10	10	-120A	
36WH1	230/1	197-253	10	69.1	2			60	30	59	3	10	10	-130A	
36WH1	230/1	197-253	15	65.9	2	60	60	60	60	59	3	10	10	-140A	
36WH1	230/3	187-264	0	18.5	1			35		22	10	10	10	4013-210A	
36WH1	230/3	187-264	6	32.9	2			35	30	22	8	10	10	-220A	
36WH1	230/3	187-264	9	40.2	2			35	45	22	6	10	10	-220A	
36WH1	230/3	187-264	15	39.5	2			35	45	22	6	10	10	-230A	
48WH1	230/1	197-253	0	30.8	1			60		37	8	10	10	4014-110A	
48WH1	230/1	197-253	5	51.6	2			60	30	37	8	10	10	-120B	
48WH1	230/1	197-253	10	72.4	2			60	60	37	8	10	10	-130B	
48WH1	230/1	197-253	15	93.3	2	60	60/30	60	80	37	8	10	8	-140B	
48WH1	230/1	197-253	20	114	2	60	60/60	60	110	37	8	10	6	-150B	
48WH1	230/3	187-264	0	20.8	1			35		24	10	10	10	4014-210A	
48WH1	230/3	187-264	9	42.5	2			35	30	24	10	10	10	-220B	
48WH1	230/3	187-264	12	49.7	2			35	40	24	8	10	10	-230B	
48WH1	230/3	187-264	15	57	2			35	45	24	6	10	10	-230B	
48WH1	230/3	187-264	18	64.2	2			35	60	24	6	10	10	-240B	

* Electric heaters are nominal Kw @ 240V.

**Based on using 60°C copper wire. Other wiring materials must be rated for marked minimum circuit ampacity or greater. Not all models approved for aluminum wire.

⚠ 48WH1, 3 Phase Rated 230/208 volt.



APPLICATION AND INSTALLATION INSTRUCTIONS

GENERAL

Units are shipped completely assembled and internally wired, requiring only duct connections, thermostat wiring and external 220-240 volt AC power supply. The refrigerant system is completely assembled and charged.

These instructions and any instructions packaged with any separate equipment should be carefully read before beginning the installation. Note particularly any tags and/or labels attached to the equipment.

While these instructions are intended as a general recommended guide, they do not supersede any national and/or local codes in any way. Authorities having jurisdiction should be consulted before the installation is made.

SHIPPING DAMAGE

Upon receipt of equipment, the carton should be checked for external signs of shipping damage. If damage is found, the receiving party must contact the last carrier immediately, preferably in writing, requesting inspection by the carrier's agent.

INSTALLATION

Size of unit for a proposed installation should be based on heat loss calculation made according to methods of National Warm Air Heating and Air Conditioning Association. The air duct should be installed in accordance with the Standards of the National Fire Protection Association for the Installation of Air Conditioning and Ventilating Systems of Other Than Residence Type, NFPA No. 90A, and Residence Type Warm Air Heating and Air Conditioning Systems, NFPA No. 90B. Where local regulations are at a variance with instructions, installer should adhere to local codes.

DUCTWORK

Design the ductwork according to methods given by the National Warm Air Heating and Air Conditioning Association. When duct runs through unheated spaces, it should be insulated with a minimum of two inches of insulation. Use insulation with a vapor barrier on the outside of the insulation. Flexible joints should be used to connect the ductwork to the equipment in order to keep the noise transmission to a minimum.

A one inch clearance to combustible material for the first three feet of duct attached to the outlet air frame is required. See pages 7, 8, 9 and 10 for further details.

FILTER

A 1" throw away filter is supplied with each unit. The filter slides into position making it easy to service. This filter can be serviced from the outside by removing the service door.

FRESH AIR INTAKE

All units are made with a fresh air inlet hole punched in the service panel. If not ordered originally, a fresh air cover with shut-off damper may be ordered from the factory. The fresh air cover is so positioned that all fresh air intake is filtered by the internal unit filter.

WALL MOUNTING

1. Two holes, the size of the supply and return air openings must be cut through the wall as shown in Fig. 1, 2, 3, 4, 5 and 6.
2. On wood-frame walls, the wall construction must be strong and rigid enough to carry the weight of the unit without transmitting any unit vibration.
3. Concrete block walls must be thoroughly inspected to insure that they are capable of carrying the weight of the installing unit.
4. Ducts through the walls must be insulated and all joints taped or sealed to prevent air or moisture entering the wall cavity.
5. Some installations may not require any return air duct. It is recommended that on this type of installation that a filter grille be located in the wall. Filters must be of sufficient size to allow a maximum velocity of 400 FPM.

WIRING - MAIN POWER

Refer to the unit rating plate for wire sizing information and maximum fuse size. Each outdoor unit is marked with a "Minimum Circuit Ampacity." This means that the field wiring used must be sized to carry that amount of current. Depending on the installed Kw of electric heat, there may be two field power circuits required. If this is the case, the unit serial plate will so indicate. Some models are suitable only for connection with copper wire, while others can be wired with either copper or aluminum wire. Each unit and/or wiring diagram will be marked "Use Copper Conductors Only" or "Use Copper or Aluminum Conductors." These instructions MUST BE adhered to. Refer to the National Electrical Code for complete current carrying capacity data on the various insulation grades of wiring material.

The electrical specifications on page 2 lists fuse and wire sizes (60°F copper) for all models, including the most commonly used heater sizes. Also shown are the number of field power circuits required for the various models with heaters.

The unit rating plate lists a "Maximum Time Delay Fuse" that is to be used with the equipment. The correct size fuse must be used for proper circuit protection and also to assure that there will be no nuisance tripping due to the momentary high starting current of the compressor motor.

WIRING - CONTROL CIRCUIT

All units are provided with a 24 volt terminal board which is marked C, G, R, Y, W1, W2, E and F. DO NOT wire to terminal C. This will cause transformer burnout. Refer to specific unit wiring diagram for details.

CONDENSATE DRAIN

A plastic drain hose extends from the drain pan at the top of the unit down to the unit base. There are openings in the unit base for the drain hose to pass through. In the event the drain hose is connected to a drain system of some type, it must be an open or vented type system to assure proper drainage.

PRESSURE SERVICE PORTS

High and low pressure service ports are installed on all units so that the system operating pressures can be observed. Pressure curves can be found later in the manual covering all models on both cooling and heating cycles. It is imperative to match the correct pressure curve to the unit by model number.

CRANKCASE HEATERS

All units are provided with some form of compressor crankcase heat. Single phase units utilize the compressor motor start winding in series with a portion of the run capacitor to generate heat within the compressor shell to prevent liquid refrigerant migration.

Three phase units utilize a wraparound type of crankcase heater that warms the compressor oil from the outside.

Some form of crankcase heat is essential to prevent liquid refrigerant from migrating to the compressor, causing oil pump out on compressor start-up and possible valve failure due to compressing a liquid.

IMPORTANT NOTICE - Be sure to follow start-up instructions as shown below and also on unit.

<p style="text-align: center;">IMPORTANT</p> <p>THESE PROCEDURES MUST BE FOLLOWED AT INITIAL START-UP AND AT ANY TIME POWER HAS BEEN REMOVED FOR 12 HOURS OR LONGER.</p> <p>TO PREVENT COMPRESSOR DAMAGE WHICH MAY RESULT FROM THE PRESENCE OF LIQUID REFRIGERANT IN THE COMPRESSOR CRANKCASE:</p> <ol style="list-style-type: none">1. MAKE CERTAIN THE ROOM THERMOSTAT IS IN THE "OFF" POSITION. (THE COMPRESSOR IS NOT TO OPERATE).2. APPLY POWER BY CLOSING THE SYSTEM DISCONNECT SWITCH. THIS ENERGIZES THE COMPRESSOR HEATER WHICH EVAPORATES THE LIQUID REFRIGERANT IN THE CRANKCASE.3. ALLOW 4 HOURS OR 80 MINUTES PER POUND OF REFRIGERANT IN THE SYSTEM AS NOTED ON THE UNIT RATING PLATE, WHICHEVER IS GREATER.4. AFTER PROPERLY ELAPSED TIME THE THERMOSTAT MAY BE SET TO OPERATE THE COMPRESSOR.5. EXCEPT AS REQUIRED FOR SAFETY WHILE SERVICING - DO NOT OPEN SYSTEM DISCONNECT SWITCH. <p style="text-align: right;">7961-061</p>
--

COMPRESSOR CUT-OFF THERMOSTAT

Heat pump compressor operation at outdoor temperatures below 0°F are neither desirable nor advantageous in terms of efficiency. Since most equipment at time of manufacture is not designed for any specific destination of the country, and most of the equipment is installed in areas not approaching the lower outdoor temperature range, the compressor cut-offs are not factory installed.

Typical wiring diagrams showing the application of a compressor cut-off can be found later in the manual on page 26.

SEQUENCE OF OPERATION

Cooling - R-Y at thermostat pulls in the compressor contactor starting the compressor and outdoor fan. The same R-Y also feeds G, which pulls in the fan relay for blower operation. The reversing valve is not energized, so the system is in the cooling cycle.

Heating - R-W (or W1) make at thermostat on a call for heat. This pulls in the changeover relay. Terminals 6-4 of changeover relay make R-Y circuit which pulls in compressor contactor starting the compressor and outdoor fan, also R-Y at thermostat completes G circuit, pulling in fan relay starting indoor blower. Terminals 1-3 on changeover relay make, energizing the reversing valve to put the system into the heating cycle. SEE REFRIGERANT FLOW DIAGRAM. The system will now be producing warm air indoors.

DEFROST CYCLE

The defrost cycle is controlled by time and temperature. When the outdoor temperature is in the lower 40°F temperature range or colder, the outdoor coil temperature is 32°F or below. This temperature is sensed by a defrost thermostat mounted low and at the return bend end of the outdoor coil. The defrost thermostat makes at approximately 32°F refrigerant temperature. The MAKE of the contacts starts the defrost timer motor. The defrost timer motor can run only when the heat pump is in operation. After approximately 30 minutes of heat pump running time, with the outdoor coil below 32°F, the defrost timer contacts make. This causes the defrost relay to pull in.

Terminals 4-5 of the defrost relay open, breaking power to the outdoor fan and the reversing valve. The outdoor fan motor stops and the reversing valve shifts to the cooling cycle. Terminals 7-9 of the defrost relay make, which pulls in W2, second stage strip heaters, with the indoor blower continuing to operate.

As the heat pump continues to operate in the defrost cycle, the outdoor coil warms up from the hot gas flow. As the temperature rises to approximately 57°F at the defrost thermostat location, the contacts now open. This de-energizes the defrost timer and defrost relay. All the components then return to the normal heating cycle as before.

EMERGENCY HEAT RELAY

It is often desired to utilize an emergency heat relay in conjunction with a special heat pump thermostat subbase to allow the operator of the equipment to easily de-energize the heat pump unit and still have total heating capability from the supplemental heaters.

The emergency heat relay is factory installed on all WH models, and a 8404-001 (Q672F1026) subbase is required to operate the relay.

INSTALLER NOTE: Optimum unit performance will occur with a refrigerant charge resulting in a suction line temperature (near the compressor) of 53° to 58°F with 95°F outdoor temperature and 80°F dry bulb/67°F wet bulb (50% R.H.) indoor temperatures and rated airflow across the indoor coil.


DIMENSIONS *

... for architect and installation requirements

MODEL	A	B	C	D	E	F	G	H	I	J	K
18WH1, 20WH, 24WH1	32½	13½	67½	20	20	8	20½	12	25¾	None	
30WH, 36WH1	38½	15½	74	22½	28	8	18	14	32¾	32	8
48WH1	42	22	84	21½	30	10	30	16	26¾	None	

FILTER SIZES*
14 x 25
15 x 30-5/8
(2) 16 x 20

* Dimensions and filter sizes are in inches.



**SUPPLY AIR METAL DUCT LINER
MODELS WA AND WH**

The cabinets on all models, with or without electric heaters, are approved for 0" clearance to combustible material. The outlet duct on all models with electric heaters must have 1" clearance to combustible materials for at least the first 3 feet of duct.

Whenever a model WA or WH is installed, a galvanized metal duct liner must always be attached (Fig. 8). Before installing, determine the wall thickness. If the installation is free air flow, with no external duct, then the liner should be cut flush with the inside wall opening. In order to insure no sweating, the duct liner should be wrapped with a minimum of 1" insulation.




Fig. 7




Fig. 8

**COOLING AND HEATING ANTICIPATION
FOR WALL THERMOSTATS**

All 24V wall thermostats are built with both cooling and heating anticipators. The purpose of these anticipators is to compensate the thermostat for various system controls and allow the best possible cycle rates.

The cooling anticipator for all thermostats, and the heating anticipator on a limited number, are fixed and require no adjustment. Most heating anticipators are adjustable and DO REQUIRE ADJUSTMENT to match the current rating of the relay, contactor or other control being cycled by that heating stage. In the case of a two stage heating thermostat there will be an anticipator for each stage, either both adjustable, one fixed and one adjustable, or both fixed.


The fixed anticipators are rated for a maximum of 1.5A. The adjustable anticipators generally have a range of .2 - 1.2A, and MUST BE ADJUSTED. Failure to adjust the anticipator lever to correspond to the actual current draw passing through that stage mercury switch and anticipator will cause severe short cycling conditions if set too low and room temperature may never attain the thermostat set point, and if set too high, will cause room temperature over-shoot.

While oil burner primary controls and gas valves are normally marked with the nominal current rating, the contactors and relays installed in air conditioners and heat pumps are not. Listed below are some of the more popularly used controls and their nominal current ratings.

Contactors or Relay	Nominal Current Rating
Honeywell - R850B Series	.55
- R8210 Series	.40
- R8212 Series	.40
- R8214 Series	.40
- R8222 Series	.38
- R8228 Series	.38
- R8242 Series	.38
- R8243 Series	.38
RBH	
- Type 84	.12
- Type 91	.34
- Type 112	.34
- Type 143	.34
- Type 154	.26
- Type 184	.12
Elmwood	
- 30E020	.38
- 30E020	.38
- 30E020	.21
- 30E030	.21
- 30E030	.21

Below is a procedure which allows accurate low amperage current measurements with a standard clamp-on ammeter with a 0-6A range. It is actually recommended that this measurement always be taken, since variations in voltage, thermostat wire length, etc. can all cause some change in current draw.

1. Wrap exactly 10 loops of thermostat wire (W1) around the prongs of an Amprobe.
2. Let the heating system operate for one minute before reading the W1 or W2 current draw.
3. Divide the reading obtained in Step 2 by 10.
4. Use the value calculated in step 3 to set the heat anticipator.
5. Repeat the procedure for (W2) if 2-stage heat.



MODELS 18WH1-20WH-24WH1

MOUNTING ON CONCRETE BLOCK WALL

These units are secured by wall mounting brackets which secure the unit to the outside wall surface at both sides and at the bottom. (Fig. 1).

In a standard 8 x 16 in. block wall, saw or knock out two 22 inch sections of concrete blocks normally the 7th, 8th and 11th course of blocks above floor level. In both cases this should be one whole block plus 3 in. of the block on each side.

On the wall, lay out approximately the position for the bottom and side brackets. Fasten these brackets to the wall firmly with 3/8 in. lag screws.

The side brackets should be located approximately 15 in. down from the top of the unit and fastened to both sides with metal screws. After mounting the unit on the wall a metal weather stripping should be installed at the top to insure a water tight application.

INSTALLATION SCHEMATIC




Fig. 1

MODELS 18WH1-20WH-24WH1

MOUNTING ON WOOD FRAME WALLS

Locate and cut out two openings as shown in (Fig. 2). Cut away the outside siding to the depth of the sheathing. Install metal weather stripping at the top and caulk or otherwise seal joints between siding and sheathing. Frame in the openings between the wall studs as necessary for the particular wall involved with the plates at the bottom of each wall opening being sufficiently strong to carry the weight of the unit.

Install the two side brackets to the unit (15 in. down from the top). Mount unit on wall and pull in firmly using three 3/8 in. lag screws through each of the wall mounting brackets.

For additional mounting rigidity, each air opening collar may be screwed to the plate at the bottom of each wall opening. Drill two 1/4 in. holes in the bottom flange of each collar before hanging the unit, then fasten to wall plate with No. 10 by 1-1/2 in. wood screws.

OUTSIDE FRAME WALL SCHEMATIC




Fig. 2

Allows 1" clearance from supply air duct from combustible materials.

MODELS 30WH-36WH1

MOUNTING ON CONCRETE BLOCK WALL

These units are secured by wall mounting brackets which secure the unit to the outside wall surface at both sides and at the bottom (Fig. 3).

In a standard 8 x 16 in. block wall, knock out two 28 in. sections of concrete blocks normally the 7th, 8th, and 11th course of blocks above floor level. In both cases this should be one whole block plus 7 in. of the block on each side.

On the wall, lay out approximately the position for the bottom and side brackets. Fasten these brackets to the wall firmly with 3/8 in. lag screws.

The side brackets should be located approximately 15 in. down from the top of the unit and fastened to both sides with metal screws. Before drilling into side of casing, check inside tubing for clearance. After mounting the unit on the wall a metal weather stripping should be installed at the top to insure a water tight application.

INSTALLATION SCHEMATIC




Fig. 3

MODELS 30WH-36WH1

MOUNTING ON WOOD FRAME WALLS

Locate and cut out two openings as shown in (Fig. 4). Cut away the outside siding to the depth of the sheathing. Install metal stripping at the top and caulk or otherwise seal joints between siding and sheathing. Frame in the openings between the wall studs as necessary for the particular wall involved with the plates at the bottom of each wall opening being sufficiently strong to carry the weight of the unit.

Install the two side brackets to the unit (15 in. down from the top). Before drilling into side of casing, check inside tubing for clearance. Mount unit on wall and pull in firmly using three 3/8 in. lag screws through each of the wall mounting brackets.

For additional mounting rigidity, each air opening collar may be screwed to the plate at the bottom of each wall opening. Drill two 1/4 in. holes in the bottom flange of each collar before hanging the unit, then fasten to wall plate with No. 10 by 1-1/2 in. wood screws.

OUTSIDE FRAME WALL SCHEMATIC




Fig. e4

Allows 1" clearance from supply air duct to combustible materials.

Model 48WH1

MOUNTING ON CONCRETE BLOCK WALL

These units are secured by wall mounting brackets which secure the unit to the outside wall surface at both sides and at the bottom (Fig. 5).

In a standard 8 x 16 in. block wall, saw or knock out two 30 in. sections of concrete blocks normally the 8th and 11th course of blocks above floor level. In both cases this should be two whole blocks.

On the wall, lay out approximately the position for the bottom and side brackets. Fasten these brackets to the wall firmly with 3/8 in. lag screws.

The side brackets should be located approximately 10 in. down from the top of the unit and fastened to both sides with metal screws. Before drilling into side of casing, check inside tubing for clearance. After mounting the unit on the wall, a metal weather stripping should be installed at the top to insure a water-tight application.

INSTALLATION SCHEMATIC

CONCRETE BLOCK WALL




Fig. 5

Model 48WH1


MOUNTING ON WOOD FRAME WALLS

Locate and cut out two 8 x 28 in. (minimum) openings as shown in (Fig. 6). Cut away the outside siding to the depth of the sheathing. Install metal weather stripping at the top and caulk or otherwise seal joints between siding and sheathing. Frame in the openings between the wall studs as necessary for the particular wall involved with the plates at the bottom of each wall opening being sufficiently strong to carry the weight of the unit.

Install the two side brackets to the unit (10 in. down from the top). Before drilling into side of casing, check inside tubing for clearance. Mount unit on wall and pull in firmly using three - 3/8 in. lag screws through each of the wall mounting brackets.



For additional mounting rigidity, each air opening collar may be screwed to the plate at the bottom of each wall opening. Drill two 1/4 in. holes in the bottom flange of each collar before hanging the unit, then fasten to wall plate with No. 10 by 1-1/2 in. wood screws.

OUTSIDE FRAME WALL SCHEMATIC








Allows 1" clearance from supply air duct to combustible materials.



Fig. 6





NOTE: 1" clearance to combustible materials required for first 3 feet of supply air duct system.



















BARD PACKAGE HEAT PUMP - 48WH1





















4013-120 Rev.A







4013-120 Rev.A















FIELD INSTALLATION OF COMPRESSOR CUT-OFF

1. Mount A-22 thermostat, Bard Part No. 8408-001, so that sensing capillary senses the air temperature in the vicinity of the outdoor fan, and shielded from the sun.





Figure A



ALPHABETICAL PARTS LIST
SINGLE PACKAGE HEAT PUMPS

PART NO.	DESCRIPTION	18WH1	20WH	24WH1	30WH	36WH1	48WH1	48WH1-3	36WH1-3	48WH1-3	460H	A09H E-THM8H
8401-007	Contact - Comp. 25A	X										X
8401-003	Contact - Comp. 30A										X	
8401-002	Contact - Comp. 25A										X	
8401-006	Contact - Heater 20A										X	
8605-001	Crankcase Heater										X	
8605-002	Crankcase Heater										X	
8408-004	Defrost Mfg. Plate										X	
8408-002	Defrost Thermostat										X	
5060-007	Evaporator Coil										X	
5060-005	Evaporator Coil										X	
5060-006	Evaporator Coil										X	
5060-021	Evaporator Coil										X	
5151-009	Fan Blade FF1827-4										X	
5151-004	Fan Blade TP2026										X	
5151-021	Fan Blade F15A24-2430										X	
7004-008	Filter 14x25										X	
7004-006	Filter 15 x 30-5/8										X	
7004-010	Filter 16x20										X	
8614-007	Fuse - Heater 60A										X	
8614-022	Fuse - Compressor 60A										X	
8614-023	Fuse - TR50										X	
8614-006	Fuse - 30A										X	
8614-013	Fuse Block 20Kw										X	
8614-014	Fuse Block 25Kw										X	
8614-019	Fuse Block 30Kw										X	
8604-041	Heat Strip 4Kw										X	
8604-043	Heat Strip 8Kw										X	
8604-042	Heat Strip 10Kw										X	
8604-044	Heat Strip 5Kw										X	
8604-048	Heat Strip 9Kw										X	
8604-046	Heat Strip 12Kw										X	
8604-049	Heat Strip 6Kw										X	
8604-047	Heat Strip 15Kw										X	
8604-050	Heat Strip 9Kw										X	
8604-051	Heat Strip 12Kw										X	
8604-052	Heat Strip 15Kw										X	
8406-010	High Pressure Switch										X	
8402-031	Limit Switch L155-2.5										X	
8402-029	Limit Switch L160-2.5										X	

ALPHABETICAL PARTS LIST
SINGLE PACKAGE HEAT PUMPS

PART NO.	DESCRIPTION	18WH1	20WH	24WH1	30WH	36WH1	48WH1	48WH1-3	36WH1-3	48WH1-3	460H	A09H E-THM8H
5202-001	Accumulator											
5202-003	Accumulator											
5202-004	Accumulator											
5202-007	Accumulator											
5152-030	Blower Housing 9-7											
5152-026	Blower Housing 10-8											
5152-028	Blower Wheel 9-7											
5152-029	Blower Wheel 9-7											
5152-011	Blower Wheel DD10-8A											
5152-012	Blower Wheel DD10-8A											
8552-007	Capacitor 20/15-370V											
8552-012	Capacitor 35/440V											
8552-001	Capacitor 4/370V											
8552-017	Capacitor 45/440V											
8552-005	Capacitor 10/370V											
8552-020	Capacitor 35/370V											
8552-022	Capacitor 20/370V											
8552-002	Capacitor 5/370V											
5811-021	Cap Tube - Cool											
5811-008	Cap Tube - Heat											
5811-017	Cap Tube - Heat											
5811-027	Cap Tube - Cool											
5811-020	Cap Tube - Heat											
5811-018	Cap Tube - Heat											
5811-014	Cap Tube - Cool											
5811-023	Cap Tube - Heat											
5811-008	Cap Tube - Cool											
5651-006	Check Valve											
8000-004	Compressor AH12LHT											
8000-005	Compressor AH14LHT											
8000-042	Compressor H2EA293AB											
8000-006	Compressor AH30LFT											
8000-009	Compressor AH302RT											
8000-02E	Compressor AG11LET											
8000-030	Compressor AG11LRT											
8000-010	Compressor AH302TT											
8000-047	Compressor AG11LUT											
5051-004	Condenser Coil											
5051-003	Condenser Coil											
5051-021	Condenser Coil											

ALPHABETICAL PARTS LIST
SINGLE PACKAGE HEAT PUMPS

PART NO.	DESCRIPTION	18WH1	20WH	24WH1	30H03	36WH1	48WH1	48WH1-3	36WH1-3	48WH1-3	48WH1-3	48WH1-3
8102-002	Motor - Blower 1/6	x	x	x	x	x	x	x	x	x	x	x
8105-003	Motor - Blower 1/3											
8106-005	Motor - Blower 1/2											
8103-009	Motor - Fan 1/5	x	x	x	x	x	x	x	x	x	x	x
8105-005	Motor - Fan 1/3											
8200-001	Motor Mount - Fan	x	x	x	x	x	x	x	x	x	x	x
8200-004	Motor Mount - Fan											
8201-008	Relay - Blower	x	x	x	x	x	x	x	x	x	x	x
8201-013	Relay - Changeover	x	x	x	x	x	x	x	x	x	x	x
8201-018	Relay - Defrost	x	x	x	x	x	x	x	x	x	x	x
8201-015	Relay - Emergency Heat	x	x	x	x	x	x	x	x	x	x	x
5650-004	Reversing Valve											
5650-005	Reversing Valve											
5650-006	Reversing Valve											
5650-002	Solenoid Coil	x	x	x	x	x	x	x	x	x	x	x
5210-004	Strainer											
5210-002	Strainer	x	x	x	x	x	x	x	x	x	x	x
5210-003	Strainer	x	x	x	x	x	x	x	x	x	x	x
8607-006	Terminal Board 24V	x	x	x	x	x	x	x	x	x	x	x
8607-001	Terminal Block 230V	x	x	x	x	x	x	x	x	x	x	x
8607-002	Terminal Block 230V	x	x	x	x	x	x	x	x	x	x	x
8607-003	Terminal Block 230V	x	x	x	x	x	x	x	x	x	x	x
8402-030	Thermal Cut-off	x	x	x	x	x	x	x	x	x	x	x
8402-032	Thermal Cut-off	x	x	x	x	x	x	x	x	x	x	x
8612-008	Timer	x	x	x	x	x	x	x	x	x	x	x
8407-015	Transformer	x	x	x	x	x	x	x	x	x	x	x
8407-004	Transformer-Stepdown	x	x	x	x	x	x	x	x	x	x	x
8407-003	Transformer-Stepdown	x	x	x	x	x	x	x	x	x	x	x