



Emergency Signal Light

T872C1004 Thermostat  
Q672F1026 Subbase

NEC Class 2  
24V Wiring

Transformer

24V Terminal Block

Change-over Relay

Rev. Valve

Blower Relay

Em. Heat Relay

Indoor-Outdoor Motor

Defrost Thermostat

Defrost Relay

Defrost Timer

240V Terminal Block

Equip. Ground

LL3 LL1

USE COPPER OR ALUMINUM WIRE

Fused Disconnect Switch

230V 60 Hz 1-Ph

- 1 3-terminal capacitor provides off-cycle crankcase heat.
- 2 Set heat anticipator at .40A.
- 3 Reroute jumper from X2-W2 to X2-E.
- 4 If emergency heat feature is not desired, use T87F or 1F56 thermostat and omit wires to E and X1.

Factory Wiring ———  
Field Wiring - - - - -

Single Package Heat Pump  
2 and 2-1/2 Ton  
One Motor