



T874C1000 Thermostat  
 Q674A1001 Subbase  
 or  
 T872C1004 Thermostat  
 Q672A1005 Subbase

Immersion  
 Crankcase  
 Heater

Compressor

Internal  
 Overload

NEC Class 2  
 24V Wiring

24V  
 Terminal  
 Block

Compressor  
 Contactor

Outdoor  
 Motor

5/370  
 Capacitor

208V

24V Transformer

5 MFD Capacitor

Limit

Blower  
 Relay

Indoor  
 Motor

Heater  
 Contactors

40A  
 Circuit  
 Breaker  
 for  
 12KW

50A  
 Circuit  
 Breaker  
 for  
 15KW

Equip.  
 Ground

Thermal  
 BLUE  
 Cut-off

YELLOW

RED

Electric  
 Heaters

USE COPPER OR  
 ALUMINUM WIRE

- 1 Set heat anticipators at .40A.
- 2 Add jumper Rc to Rh.
- 3 Remove jumper W1-W2 for 2-stage heat.
- 4 For 208V operation move this wire to 208V transformer tap.

230/208-60-3

Factory Wiring \_\_\_\_\_  
 Field Wiring - - - - -

4009231G