



USE COPPER CONDUCTORS
ONLY SUITABLE FOR AT
LEAST 75° C

ALR	INDOOR BLOWER CAPACITOR
CB1	INDOOR BLOWER MOTOR
CB2	INDOOR BLOWER RELAY
CC	INDOOR BLOWER CONTROL
CCH	LOW AMBIENT CONTROL
CHR	CRANKCASE HEATER
COMP	COMPRESSOR CONTROL MODULE
CONP	CRANKCASE HEAT RELAY
GND	COMPRESSOR
H1	EQUIPMENT GROUND
H2	HEAT STRIP #1
H2	HEAT STRIP #2
H2	HEATER CONTACTOR #1
H2	HEATER CONTACTOR #2
HFC	HIGH PRESSURE CONTROL

IBM <th>INDOOR BLOWER MOTOR</th>	INDOOR BLOWER MOTOR
IBR	INDOOR BLOWER RELAY
LAC	INDOOR BLOWER CONTROL
LPC	LOW AMBIENT CONTROL
LS	LIMIT SWITCH
DFC	OUTDOOR FAN CAPACITOR
DFM	OUTDOOR FAN MOTOR
PL1	PLUG #1
PM	PHASE MONITOR
T	TRANSFORMER
TB, TB2	TERMINAL BLOCK
TBL	LOW VOLTAGE TERMINAL BLOCK
TCC	THERMAL CUTOFF

IB	INDOOR BLOWER MOTOR
IBM	INDOOR BLOWER MOTOR
IBR	INDOOR BLOWER RELAY
LAC	INDOOR BLOWER CONTROL
LPC	LOW AMBIENT CONTROL
LS	LIMIT SWITCH
DFC	OUTDOOR FAN CAPACITOR
DFM	OUTDOOR FAN MOTOR
PL1	PLUG #1
PM	PHASE MONITOR
T	TRANSFORMER
TB, TB2	TERMINAL BLOCK
TBL	LOW VOLTAGE TERMINAL BLOCK
TCC	THERMAL CUTOFF

IB	INDOOR BLOWER MOTOR
IBM	INDOOR BLOWER MOTOR
IBR	INDOOR BLOWER RELAY
LAC	INDOOR BLOWER CONTROL
LPC	LOW AMBIENT CONTROL
LS	LIMIT SWITCH
DFC	OUTDOOR FAN CAPACITOR
DFM	OUTDOOR FAN MOTOR
PL1	PLUG #1
PM	PHASE MONITOR
T	TRANSFORMER
TB, TB2	TERMINAL BLOCK
TBL	LOW VOLTAGE TERMINAL BLOCK
TCC	THERMAL CUTOFF

△, ▽ LABELLED WIRES CONNECT IF NO OPTIONS USED.

△ MOVE RED WIRE TO 208V TAP FOR 208V OPERATION

▽ RED (LOW) BLACK (HIGH) WERE APPLICABLE

BLACK	BROWN	RED	DRANGE	Y	G	BL	W	V	PR	GY	SLATE	TAN	PINK	LAVERNER
BK	BR	R	D	Y	G	BL	W	YELLOW	GREEN	BLUE	WHITE	TAN	PINK	LAVERNER
								VIOLLET	PURPLE	GRAY	SLATE			
								YELLOW	GREEN	BLUE	WHITE	TAN	PINK	LAVERNER
								VIOLLET	PURPLE	GRAY	SLATE			
								YELLOW	GREEN	BLUE	WHITE	TAN	PINK	LAVERNER

COMPONENT CODE

BARB MFG. CO.

4095-231 D