



USE COPPER CONDUCTORS ONLY
SUITABLE FOR AT LEAST 75° C

COMPONENT CODE			
CB1	CIRCUIT BREAKER #1	ERV	ENERGY RECOVERY VENTILATOR
CB2	CIRCUIT BREAKER #2	FT	FREEZE T-STAT
CC	COMPRESSOR CONTACTOR	GND	EQUIPMENT GROUND
COMP	COMPRESSOR	H1	HEAT STRIP #1
CR1	CONTROL RELAY #1	H2	HEAT STRIP #2
CR2	CONTROL RELAY #2	HC1	HEATER CONTACTOR #1
CR3	CONTROL RELAY #3	HC2	HEATER CONTACTOR #2
CR4	CONTROL RELAY #4	HPC	HIGH PRESSURE CONTROL
CR5	CONTROL RELAY #5	IBC	INDOOR BLOWER CAPACITOR
CR6	CONTROL RELAY #6	IBM	INDOOR BLOWER MOTOR
DCC	DUAL CAN CAPACITOR	IBR	INDOOR BLOWER RELAY
DFC	DEFROST CONTROL	LAB	LOW AMBIENT BYPASS CONTROL
EMR	EMERGENCY HEAT RELAY	LAC	LOW AMBIENT CONTROL
		LPB	LOW PRESSURE BYPASS
		LPC	LOW PRESSURE CONTROL
		LS	LIMIT SWITCH
		OFM	OUTDOOR FAN MOTOR
		PL1	PLUG #1
		RAT	RETURN AIR THERMOSTAT
		RV	REV. VALVE SOLENOID
		SK	START KIT
		T	TRANSFORMER
		TB	TERMINAL BLOCK
		TBL	LOW VOLTAGE TERMINAL BLOCK
		TCO	THERMAL CUTOFF
		TWV	THREE WAY VALVE
		TDR	TIME DELAY RELAY

A, B LABELED WIRES CONNECT IF NO OPTIONS USED.
 C MOVE RED WIRE TO 208V TAP FOR 208V OPERATION
 D RED (LOW) BLACK (HIGH) WHERE APPLICABLE

		COLOR CODE									
HIGH VOLTAGE	FACTORY STD. 	FIELD 	OPTIONAL 	BK	BLACK	Y	YELLOW	V	VIOLET	T	TAN
LOW VOLTAGE				BR	BROWN	G	GREEN	(PR)	PURPLE	PK	PINK
ACCESSORY				R	RED	BL	BLUE	GY	GRAY	L	LAVENDER
				O	ORANGE	W	WHITE	(S)	SLATE		

BARD MFG. CO.

4096-121 E