



USE COPPER CONDUCTORS ONLY
SUITABLE FOR AT LEAST 75° C

COMPONENT CODE

| | | | | | |
|------|----------------------------|-----|----------------------------|-----|----------------------------|
| CB1 | CIRCUIT BREAKER #1 | HC2 | HEATER CONTACTOR #2 | RLB | RELAY LOGIC BOARD |
| CB2 | CIRCUIT BREAKER #2 | HPC | HIGH PRESSURE CONTROL | RV | REV. VALVE SOLENOID |
| CC | COMPRESSOR CONTACTOR | IBC | INDOOR BLOWER CAPACITOR | SK | START KIT |
| COMP | COMPRESSOR | IBM | INDOOR BLOWER MOTOR | T | TRANSFORMER |
| DCC | DUAL CAN CAPACITOR | IBR | INDOOR BLOWER RELAY | TB | TERMINAL BLOCK |
| DFC | DEFROST CONTROL | LAB | LOW AMBIENT BYPASS CONTROL | TBL | LOW VOLTAGE TERMINAL BLOCK |
| EMR | EMERGENCY HEAT RELAY | LAC | LOW AMBIENT CONTROL | TCD | THERMAL CUTOFF |
| ERV | ENERGY RECOVERY VENTILATOR | LPB | LOW PRESSURE BYPASS | TWV | THREE WAY VALVE |
| FT | FREEZE T-STAT | LPC | LOW PRESSURE CONTROL | | |
| GND | EQUIPMENT GROUND | LS | LIMIT SWITCH | | |
| H1 | HEAT STRIP #1 | OFM | OUTDOOR FAN MOTOR | | |
| H2 | HEAT STRIP #2 | PL1 | PLUG #1 | | |
| HC1 | HEATER CONTACTOR #1 | RAT | RETURN AIR THERMOSTAT | | |

A, **B** LABELED WIRES CONNECT IF NO OPTIONS USED. **△** MOVE RED WIRE TO 208V TAP FOR 208V OPERATION **△** RED (LOW) BLACK (HIGH) BLUE (MEDIUM) WHERE APPLICABLE

| HIGH VOLTAGE | FACTORY STD. | FIELD | OPTIONAL | COLOR CODE | | | | | | | | | | | | | | |
|--------------|--------------|---------|----------|------------|-------|-----|--------|--------|-------|------|-------|--------|--------|------|-------|-----|------|----------|
| | | | | BK | BR | R | O | Y | G | BL | W | V | (PR) | GY | (S) | T | PK | L |
| LOW VOLTAGE | ———— | - - - - | · · · · | BLACK | BROWN | RED | ORANGE | YELLOW | GREEN | BLUE | WHITE | VIOLET | PURPLE | GRAY | SLATE | TAN | PINK | LAVENDER |
| ACCESSORY | ———— | - - - - | · · · · | | | | | | | | | | | | | | | |

BARD MFG. CO.
4096-131 A