



USE COPPER CONDUCTORS ONLY
SUITABLE FOR AT LEAST 75° F

COMPONENT CODE	
CB1	CIRCUIT BREAKER #1
CB2	CIRCUIT BREAKER #2
CC	COMPRESSOR CONTACTOR
CCH	COMPRESSOR CRANKCASE HEATER
COMP	COMPRESSOR
DFC	DEFROST CONTROL
EHF	EMERGENCY HEAT RELAY
GND	EQUIPMENT GROUND
H1	HEAT STRIP #1
H2	HEAT STRIP #2
HC1	HEATER CONTACTOR #1
HC2	HEATER CONTACTOR #2
HPC	HIGH PRESSURE CONTROL
IBC	INDOOR BLOWER CAPACITOR
IBM	INDOOR BLOWER MOTOR
IBR	INDOOR BLOWER RELAY
LAB	LOW AMBIENT BYPASS CONTROL
LAC	LOW AMBIENT CONTROL
LFB	LOW PRESSURE BYPASS
LPC	LOW PRESSURE CONTROL
LS	LIMIT SWITCH
DFC	OUTDOOR FAN CAPACITOR
DFR	OUTDOOR FAN RELAY
PL1	PLUG #1
RV	REV. VALVE SOLINOID
T	TRANSFORMER
TB	TERMINAL BLOCK
TBL	LOW VOLTAGE TERMINAL BLOCK
TCD	THERMAL CUTOFF

▲, ▲ Labeled wires connect if no options used. ▲ MOVE RED WIRE TO 208V TAP FOR 208V OPERATION ▲ RED (LOW) BLACK (HIGH) WHERE APPLICABLE ▲ REMOVE JUMPER FOR OUTDOOR THERMOSTAT

FACTORY STD.		FIELD		OPTIONAL	
HIGH VOLTAGE	————	----	----	----	----
LOW VOLTAGE	————	----	----	----	----
ACCESSORY	————	----	----	----	----

COLOR CODE					
BK	BLACK	Y	YELLOW	V	VIOLET
BR	BROWN	G	GREEN	(PR)	PURPLE
R	RED	BL	BLUE	GY	GRAY
O	ORANGE	W	WHITE	(S)	SLATE
		T	TAN	PK	PINK
		L	LAVENDER		

BARD MFG. CO.
4096-210 G