



| COMPONENT CODE | |
|----------------|----------------------------|
| CB1 | CIRCUIT BREAKER #1 |
| CB2 | CIRCUIT BREAKER #2 |
| CC | COMPRESSOR CONTACTOR |
| COMP | COMPRESSOR |
| DFC | DEFROST CONTROL |
| EHR | EMERGENCY HEAT RELAY |
| GND | EQUIPMENT GROUND |
| H1 | HEAT STRIP #1 |
| H2 | HEAT STRIP #2 |
| HC1 | HEATER CONTACTOR #1 |
| HC2 | HEATER CONTACTOR #2 |
| HPC | HIGH PRESSURE CONTROL |
| IBC | INDOOR BLOWER CAPACITOR |
| IBM | INDOOR BLOWER MOTOR |
| IBR | INDOOR BLOWER RELAY |
| LAB | LOW AMBIENT BYPASS |
| LAC | LOW AMBIENT CONTROL |
| LPB | LOW PRESSURE BYPASS |
| LPC | LOW PRESSURE CONTROL |
| LS | LIMIT SWITCH |
| DOT | OUTDOOR THERMOSTAT |
| DFC | OUTDOOR FAN CAPACITOR |
| DFM | OUTDOOR FAN MOTOR |
| DMT | OUTDOOR MOTOR THERMOSTAT |
| PL1 | PLUG #1 |
| PM | PHASE MONITOR |
| RV | REV. VALVE SOLINOID |
| T | TRANSFORMER |
| TB, TB2 | TERMINAL BLOCK |
| TBL | LOW VOLTAGE TERMINAL BLOCK |
| TCD | THERMAL CUTOFF |

USE COPPER CONDUCTORS ONLY
SUITABLE FOR AT LEAST 75° C

| | | | | | | | | | | | |
|--|--|--|---|--------|----|---|------|--------|---|----------|---|
| | | | | | | | | | | | |
| <p>Labeled wires connect if no options used.</p> | | | <p>MOVE RED WIRE TO 208V TAP FOR 208V OPERATION</p> | | | <p>RED (LOW) BLACK (HIGH) BLUE (MED) WHERE APPLICABLE</p> | | | <p>REMOVE JUMPER FOR OUTDOOR THERMOSTAT</p> | | |
| <p>FACTORY STD. FIELD OPTIONAL</p> | | | <p>COLOR CODE</p> | | | | | | | | |
| <p>HIGH VOLTAGE ——— - - - - - -</p> | | | BK | BLACK | Y | YELLOW | V | VIOLET | T | TAN | <p>BARD MFG. CO. 4096-216 D</p> |
| <p>LOW VOLTAGE ——— - - - - - -</p> | | | BR | BROWN | G | GREEN | (PR) | PURPLE | PK | PINK | |
| <p>ACCESSORY ——— - - - - - -</p> | | | R | RED | BL | BLUE | GY | GRAY | L | LAVENDER | |
| | | | O | ORANGE | W | WHITE | (S) | SLATE | | | |
| | | | | | | | | | | | |